



**Valid for**

Dart

**OSes**

**Exceptions**

**Using the front panel controls...**

Push the ESC key on the keypad.

Push the Down Arrow key on the keypad.  
SHUTDOWN will be displayed.  
Push the OK button.

Push the Down Arrow key on the keypad twice, or until...  
SYSTEM HALT is displayed.  
Push the OK button.

The unit will power down.